<u>User manual</u> <u>Tuya smart</u>

Product: Smart mechanical light switch


060 319 2282 or WhatsApp

072 604 4306 or WhatsApp



henractech.sales@outlook.com

Wiring diagram



Ĵ	1 2 3 4
- Live out to the lights:	
Yellow wire	Light 1


→ Light 2

Blue wire

White wire \longrightarrow Light 3

Orange wire ----- Light 4

	Before you connect the device to the app, power it on & see if there is a blue LED flashing from the Wi-Fi switch module, if there is no blue light, lift the garage module & you'll see a button. Press & hold the button for 5 seconds until the blue light flashes. Reset
Step 1	button
	After confirming a flashing blue light, proceed to the Smart Life or Tuya Smart app and press the '+' icon to add the device.
Step 2	
	ces ····
	Once you've tapped on add devices, the Wi-Fi switch module should automatically be picked up. Tap on the blue add button. Searching for nearby devices. Make sure your device has entered pairing mode.
Step 3	Discovering devices Add



	The device will pair with your application, the device will be added within 2 min. If failed, check your WiFi details & confirm the blue LED is flashing rapidly.
	Connecting Device
	Keep the network stable.
Step 7	Q
	01:56
	01100
Step 8	When the smart device pops up in pairing mode, tap on add, & confirm your WiFi network to which the device will be connected. To learn how to rename the device & switches [click here]. Enter Wi-Fi Information Choose Wi-Fi and enter password
	🛜 HTECH 🔤
	≙ ⊨ • ∞
Step 9	Once your device has been added, it is time to test it. Go into your smart app and switch on a switch, then manually switch off your light.

<u>Warranty</u>

WARRANTY POLICY for REPLACEMENTS

Should any product 'fail' within the first 3 months of purchase the product may be returned to us for either a repair or replacement. From your nearest PostNet branch country request the standard 'PostNet to PostNet' service.

For more details regarding our return policy [Click Here]

IMPORTANT! Warranty void if:

- 1) Goods are not in original packaging & are complete with all original components.
- 2) Goods show signs of damage due to abusive usage.
- 3) Goods show signs of physical alteration.
- 4) Goods show signs of physical damage.
- 5) Goods show signs of tampering.
- 6) Signs of power spike damage.
- 7) Signs of water damage (besides waterproof products).